
Numerics

14-bit Controllers F-1
440-tuned piano voice 3-3
64-Note Poly bank 3-4
64-note polyphony 3-4, 5-7, A-1

A

All Notes Off 9-4, F-6
All Sound Off 5-13, F-6
Alpha Wheel 1-4, 2-7
Alternating maps 5-7
Arp Active 6-2
Arpeggiator
 copying 5-18, 6-6
 MIDI control of 6-6
 shifting notes 6-4
Arpeggiator Active 6-2, F-5
Arpeggiator button 6-1
Arpeggiator Latch F-5
Arpeggiator Latch 1 2-10
Arpeggiator Velocity F-5
Assignable controllers
 default settings 2-9
Assignable Controllers, Buttons, and Wheels 2-9
Attack Time F-3
Audio connections 2-1
Automatic reset 2-7

B

Balance F-2
Bank Mode 5-5
Bank numbers
 sending 5-5
Bank Sel Ctl 9-4
Bank Select 5-13, F-1
Bank Select Control 9-4
Banks 5-3
 VGM 3-4
Battery 1-8
Beat tuning 3-3
Beats
 with Arpeggiator 6-4
BndRng (ct) 5-2
BndRng (ST) 5-2
Breath
 sending to other devices F-1
Breath Controller 5-13
Bright 7-1
Brightness F-3
Buttons 5-11
 Arpeggiator 6-1

Controllers 5-11
Copy 5-17
Effects 2-10, 7-1
Global 9-1
Key Range 5-6
MIDI Receive 8-1
MIDI Transmit 5-2
Next Group 3-1
Panic 2-10
Previous Group 3-1
Program 5-3
Store 5-19
Transpose 5-7
Velocity 5-8

C

Change Setups 9-3
Channel On/Off
 MIDI Receive 8-1
Chg Setups 9-3
Chorus 1 7-1
Chorus 2 7-1
Click 3-3
Clock 9-2
Coarse Tuning F-5
Connections
 audio 2-1
 MIDI 2-2
 pedals 2-2
 power 2-1
Continuous Control Pedals 2-2
Continuous controllers 5-12, F-1
 copying 5-18
Controllers
 assignable 2-9
 assigning 1-4
 continuous 5-11
 scaling 5-14
 switch 5-11, 5-15
Controllers button 5-11
Copy button 5-17
Copying effects 7-3
Copying the Arpeggiator 6-6
Copying Zone parameters 5-17
Cos+
 velocity curve 5-8
Creating a Setup 4-4
Ctrl Curve 5-14
Ctrl Offset 5-14
Ctrl Scale 5-14
Cursor Buttons 2-3

D

- Damper F-3
- Data Decrement F-4, F-5
- Data Entry 2-7, F-1
- Data Entry Slider 5-13
- Data Increment F-4, F-5
- Data Slider F-5
- Decrement/increment buttons 2-7
- Default settings
 - resetting parameters to 2-7
- Delay 7-1
- Deleting setups 5-20
- Demo sequence 1-3
- Dest 5-2
- Destination 5-2
- Device ID 9-4
- Diagnostics G-1
- Drum Sounds
 - and effects 7-3
- Drums C-1
 - Kurzweil C-3
 - Latin percussion C-5
 - orchestral percussion C-6
- Dump all Setups 9-5
- Dumping setups 5-20
- Duration
 - with Arpeggiator 6-4

E

- Effect
 - copying 5-18
- Effect Control
 - sending to other devices F-2
- Effects 1-7, D-1
 - and drum sounds 7-3
 - copying 7-3
 - MIDI control of 7-4
 - saving 7-2
- Effects button 2-10, 7-1
- Effects Change Mode 9-2
- Effects Depth 2-9, 5-13
- Efx Chg Mode 9-2, 9-3
- Ensemble tuning 3-3
- Entry transmit 5-4
- Entry values 5-15
- Envelope F-3
- Envelope Control 2-10, 5-13
- Exit values 5-15
- Exiting from PC88 Menus 1-4
- Exiting without changing a Setup 1-7
- Expansion Sounds bank 3-4

- Expansion voices B-2
- Expression 2-2, 5-13, F-2

F

- Fine Tuning F-5
- Fixed Velocity
 - with Arpeggiator 6-4
- Foot Control 5-13
- Foot Pedal 2-2, 2-10
- Freeze 5-13

G

- General MIDI 9-4, B-1
 - drum sounds C-1
- General MIDI bank 3-4
- General MIDI mode 8-2
- General Purpose Controllers F-2
- Gigs
 - using PC88 at 10-1
- Glissando
 - with Arpeggiator 6-6
- Global button 9-1
- Global parameters 9-1
- Goto Program 5-14
- Goto Setup 5-14
- Group buttons 3-1
- Groups 3-1

H

- Hall 7-1
- Hard reset 9-5
- Harmonic Content F-3
- Hi
 - key range 5-6
- Hold 2 5-13

I

- Initial Tempo
 - with Arpeggiator 6-4
- Int Eff Delay 7-2
- Int Eff Wet 7-2
- Int Rev Time 7-2
- Int Rev Wet 7-2
- Internal 1-4
- Internal Effects Delay 7-2
- Internal Effects Wet 7-2
- Internal Reverb Time 7-2
- Internal Voices 1-4, 3-1, A-1
- Internal voices
 - customizing 3-3

IntFx 7-2
Intuitive entry 1-4, 1-6, 2-7, 5-12

J

Joystick
 sending to other devices F-2
Jump editing 2-9

K

K1000
 bank mode 5-5
K2000
 bank mode 5-5
Key Range
 with Arpeggiator 6-2
Key Range button 5-6
Kurzweil drums C-3

L

Latch Mode 6-3
Latching 6-3
Latin percussion kit C-5
LCD Contrast Adj. 2-3
Least Significant Byte (LSB) F-1, F-4
Left (Mono) jack 2-1
Legato Footswitch F-3
Limit Option
 with Arpeggiator 6-5
Linear
 velocity curve 5-8
Local Control 9-2
Local Control Off F-6
Low
 key range 5-6

M

Main Volume F-1
Maintenance
 battery 1-8
Master Volume 2-10
Mem avail 9-5
Memory
 battery-backed 1-8
Memory available 9-5
Menus
 exiting from 1-4
Merge
 with MIDI In 9-4
Metronome Click 3-3
MIDI Channel 5-2

MIDI composing studio
 using PC88 in 10-2
MIDI connections 2-2
MIDI control of effects 7-4
MIDI controllers 5-13
 available with Arpeggiator 6-6
MIDI In 9-3
MIDI Receive
 channel on/off 8-1
 Program parameter 8-1
MIDI Receive button 8-1
MIDI Setups 1-5, E-1
MIDI Transmit button 5-2
MIDIScope 9-6
Mode messages F-1
Modulation 2-9, 5-13, F-1
Momentary
 switch type 5-15
Mono On F-6
Most Significant Byte (MSB) F-1, F-4
MPressure 5-11
Music Rack 1-3

N

Naming Setups 5-19
Next Group button 3-1
Non-Registered Parameter F-4
Normal 7-1
Note Map 5-6
Note Shift
 with Arpeggiator 6-4
Numeric keypad 2-7

O

Omni Off F-6
Omni On F-6
Orchestral percussion C-6

P

Pan 5-13, F-2
Panic button 2-10, E-4
Parameters 5-1
 global 9-1
 selecting 4-2
PC88
 product description 1-1
 unpacking 1-2
 using at a gig 10-1
 using in MIDI composing studio 10-2
 using in recording studio 10-1
PC88mx 1-7

- Pedal connections 2-2
- Pedal controllers
 - default settings 2-2
- Pedals 5-11, 5-17
- Piano voices
 - 440-tuned 3-3
- Pitch Bend Sensitivity F-5
- Pitch Down 5-13
- Pitch Up 5-13
- Pitchbend down 2-9
- Pitchbend Range 5-2
- Pitchbend up 2-9
- Play Order
 - with Arpeggiator 6-3
- PNameDisp 5-6
- PNumDisp 5-5
- Poly On F-6
- Polyphony
 - 64-note 5-7
- Portamento 5-13, F-3
- Portamento Control F-4
- Portamento Switch F-1, F-4
- Portamento Time F-1, F-4
- Power connection 2-1
- Pressure 5-13
- Previous Group button 3-1
- Program
 - with MIDI Receive 8-1
- Program button 5-3
- Program Change commands 3-2
- Program Decrement 5-14
- Program Increment 5-14
- Program Name Display 5-6
- Program numbers 3-2
 - displaying 5-5

R

- Receive 8-1
- Receive Transpose 9-4
- Recording studio
 - using PC88 in 10-1
- Recv Trans 9-4
- Registered Parameter F-4
- Release Time F-3
- Remap
 - with MIDI In 9-3
- Reset 9-5
- Reset All Controllers 5-13, F-6
- Reset PC88 9-5
- Reverb Depth 2-9, 5-13
- Ride Cymbal 3-3
- Roland

- using All Notes Off with 9-4
- Room 7-1

S

- Saving Effects 7-2
- Scaling controllers 5-14
- Scaling velocity 5-8
- Sequence Continue 5-14
- Sequence Start 5-14
- Sequence Stop 5-14
- Sequencer
 - using the PC88 with 8-1
- Setting up the PC88 1-2
- Setup Change Channel 9-3
- Setup chg chan 9-3
- Setup Decrement 5-14
- Setup Increment 5-14
- Setups 1-5, 4-1, E-1
 - changing 9-3
 - creating from an Internal Voice 4-4
 - deleting 5-20
 - dumping 5-20
 - naming 5-19
 - storing 5-19
 - template E-5
 - VGM E-3
- Shift Limit
 - with Arpeggiator 6-5
- Shifting notes
 - in the Arpeggiator 6-4
- Sin+
 - velocity curve 5-8
- Sliders 5-11
- Soft 5-13
- Soft Pedal A-1, F-3
- Soft reset 9-5
- Solo button 1-5, 2-5
- Solo tuning 3-3
- Sostenuto 2-2, 5-13, F-3
- Sound Control 2 2-10
- Sound Controller 3 5-13
- Sound Controllers F-3
- Sound Variation F-3
- Sound/Setup Select 2-4
- Specifications iv
- Stage 7-1
- Store button 1-7, 4-4, 5-19
 - with Effects 7-2
 - with Internal Voices 3-3, 5-1
- Storing a setup 5-19
- Stretch tuning 3-3
- Sustain 2-2, 5-13, F-3

Switch controller
 copying 5-18
Switch controllers 5-15, F-2
Switch Pedals 2-2
SwitchPdl 5-11

T

Tempo 5-13
Toggle
 switch type 5-15
Touch 9-2
Transmit Buttons 9-5
Transmit Clock 9-2
Transmit Reverb Sysex 9-5
Transpose button 5-7
Transpose Down 5-14
Transpose Up 5-14
Tuning 9-4
Tuning Bank Select F-5
Tuning Program Select F-5

U

Unpacking the PC88 1-2

V

Vel Curve 5-8
Vel Max 5-8
Vel Min 5-8
Vel Offset 5-8
Vel Scale 5-8
Velocity button 5-8
Velocity Curve 5-9
Velocity Maximum 5-10
Velocity Minimum 5-10
Velocity Mode
 with Arpeggiator 6-4
Velocity Offset 5-8
Velocity Scale 5-8
VGM banks 3-4
VGM board 1-7, 8-2
VGM Eff Delay 7-3
VGM Eff Wet 7-3
VGM effects 7-3
VGM Rev Time 7-3
VGM Rev Wet 7-3
VGM Setups E-3
VGM voices B-1
VGMFx 7-3
Volume 5-13
 master 2-10

W

Warm 7-1
Wheel 1 Down 5-11
Wheel 1 Up 5-11
Wheel 2 5-11

X

XMit Buttons 9-5
Xmit Rvb Sysex 7-4, 9-5

Z

Zone button lights 4-3
Zone buttons 1-5, 2-4
Zone Enable
 with Arpeggiator 6-2
Zone parameters 2-5, 5-1
 and Internal Voices 5-1
 copying 5-17
 selecting 4-2
Zones 4-1
 active 2-4, 4-2
 copying 5-18
 current 2-4, 4-2
 muted 2-4, 4-2
 selecting 4-2
 soloed 2-4, 4-2

