

K2500 / X      Setup Mode  
(Continuous Controller)

## Setup Mode

## SLIDER Page

## SLIDER

Edit Setup : SLIDER &lt;&gt;Zone 1 / 1

	Dest :	Scale:	Add:	Curve:	Ent:	Exit:
SlidA:	Off	100 %	0	Lin	None	None
SlidB:	Off	100 %	0	Lin	None	None
SlidC:	Off	100 %	0	Lin	None	None
SlidD:	Off	100 %	0	Lin	None	None

<more SLIDER SLID/2 FOOTSW CPEDAL more>

Slider A D 4  
Dest(Destination)- 가 -  
(Scale, Add, Curve ) , (Ent, Exit)

**Dest** (Destination) -

Slid A	Dest(Destination)	Volume	Slider A
	(Control Source)	가	7-21

**Scale** – KEYVEL Page VelScale .

**Add -** KEYVEL Page VelOffset .

<b>Curve</b> (Curve) -	KEYVEL Page	VelCurve	.
Curve	Performance Guide Manual	7-13	7-14

**Ent** (Entry Value ) -

**Exit** (Exit Value ) -

SLID/2 Page

SLID/2

Edit Setup : SLID/2 <>Zone 1 / 1						
	Dest :	Scale:	Add:	Curve:	Ent:	Exit:
SlidE:	Off	100 %	0	Lin	None	None
SlidF:	Off	100 %	0	Lin	None	None
SlidG:	Off	100 %	0	Lin	None	None
SlidH:	Off	100 %	0	Lin	None	None
<more	SLIDER	SLID/2	FOOTSW	CPEDAL	more>	

SLID/2 E H 4  
Dest(Destination)- 가 -  
(Scale,Add, Curve ) , (Ent, Exit)

CPEDAL RIBBON, WHEEL, PRESS ( )  
. ( RIBBON RIBCFG  
가 .)

CPEDAL, RIBBON , WHEEL , PRESS

CPEDAL Page

CPEDAL

Edit Setup : CPEDAL <>Zone 1 / 1						
	Dest :	Scale:	Add:	Curve:	Ent:	Exit:
CPed1:	Off	100 %	0	Lin	None	None
CPed2:	Off	100 %	0	Lin	None	None
<more	SLIDER	SLID/2	FOOTSW	CPEDAL	more>	

CPEDAL CC Pedal 1 2  
Dest(Destination) (Scale,Add, Curve ) ,  
(Ent, Exit)

**RIBBON**    **Page**  
**RIBBON**

Edit Setup : RIBBON						<>Zone 1 / 1
	Dest :	Scale:	Add:	Curve:	Ent:	Exit:
SmRib:	AuxBend2	100 %	0	Lin	None	None
SmPrs:	MPress	100 %	0	Lin	None	None
LgRib:	AuxBend1	100 %	0	Lin	None	None

<more    SLIDER    SLID / 2    FOOTSW    CPEDAL    more>

RIBBON  
Dest(Destination) (Scale,Add, Curve ) ,  
(Ent, Exit)

(SmRib) (SmPrs)  
가 ( )

RIBCFG  
3 3

Edit Setup : RIBBON						<>Zone 1 / 1
	Dest :	Scale:	Add:	Curve:	Ent:	Exit:
SmRib:	AuxBend2	100 %	0	Lin	None	None
SmPrs:	MPress	100 %	0	Lin	None	None
Sect1:	AuxBend1	100 %	0	Lin	None	None
Sect2:	Ctl D	100 %	0	Lin	None	None
Sect3:	MIDI20	100 %	0	Lin	None	None

<more    SLIDER    SLID / 2    FOOTSW    CPEDAL    more>

**WHEEL**    **Page**  
**WHEEL**

Edit Setup : WHEEL						<>Zone 1 / 1
	Dest :	Scale:	Add:	Curve:	Ent:	Exit:
PWhl :	BendUp	100 %	0	Lin	None	None
MWhl :	MWheel	100 %	0	Lin	None	None

<more    SLIDER    SLID / 2    FOOTSW    CPEDAL    more>

WHEEL  
Dest(Destination)  
(Ent, Exit) (Scale,Add, Curve ) ,  
.

**PRESS** **Page**  
**PRESS**

Edit Setup : PRESS <>Zone 1 / 1  
Dest : Scale: Add: Curve: Ent: Exit:  
Press: MPress 100 % 0 Lin None None

<more SLIDER SLID / 2 FOOTSW CPEDAL more>

PRESS After Touch Dest(Destination)  
(Scale,Add, Curve ) , (Ent, Exit)  
.

Continuous Controller  
가

Continuous Controller  
(Switch Controller)  
..)