

7. Quick Access Mode

K2500 / X Quick Access Mode

Quick Access ...

Quick Access (Mode) 10

) (

1. Quick Access Bank

Q.Access (Quick Access) Quick Access

```
QuickAccessMode <>Bank:1 For Show 1
Silk Rhodes POLY TOUCH Voice+String
NastyTrombone SINK MONSTA Waterflute
Soon Jazz Trio 2 Fretless Bas
VELVETEEN
```

```
Xpose:0ST SINK MONSTA Chan:1
Octav- Octav+ Panic Sample Chan- Chan+
```

QuickAccessMode <> Bank:1 For Show 1

QuickAccessMode - Quick Access Mode

<>Bank : 1 - 1
 Chan/Bank (,)
 Chan/Bank 가 (<>Bank : 2, <>Bank : 3 ,
 ...) 10

For Show 1 - For Show
 1

10 (Silk Rhodes , POLY TOUCH ,
 Voice+String ,NastyTrombone, SINK MONSTA ...)

2. Keypad

			10	10	Keypad(0 ~ 9	가
)			.			
Silk Rhodes	POLY TOUCH	Voice+String	1	2	3	
NastyTrombone	SINK MONSTA	Waterflute	4	5	6	
Soon	Jazz Trio2	Fretless Bas	7	8	9	
VALVETEEN			0			
10			Keypad			

Fretless Bas

9

3.

4. +, -
 ● -
 +
 -

Quick Access Mode +, -
 (+) (-)
 Silk Rhodes POLY TOUCH Voice+String → Silk Rhodes POLY TOUCH Voice+String
 NastyTrombone SINK MONSTA Waterflute + NastyTrombone SINK MONSTA Waterflute

Access Bank Quick

(List)

Quick Access Mode 가 Bank 9 : Basic QA Bank
Edit .

Edit Quick Access <> **Entry : 0**

198 Click
199 Default Program
Entry : Type : **1 Acoustic Piano**
2 Stage Piano
3 Brite Grand
4 ClassicPiano&Vox

Name **Save** **Delete** **Dump**

Edit Quick Access - Quick Access .

<> Entry : 0 - Entry Quick Access Mode . <> Entry : 0
()
0
.

Entry - Entry Quick Access Mode (0 0 . Entry
)

Chan/Bank (,)
Entry .

Type - .

Name - .
.

Save - . Save
Save .

Delete - . Delete
Delete 가 .

Dump - Quick Access bank

K2500/X Quick Access Mode .
K2500/X Effect Mode .